

MONSTER



MAG FLUX

**WIRELESS
BLUETOOTH® SPEAKER**

QUICK START GUIDE

SAFETY AND CARE INSTRUCTIONS

Read all the instructions before using the product and then store them for future reference:

- Noise is measured in decibels (dB). Long-term exposure to noise levels of 85dB or higher can gradually cause hearing loss. To protect your hearing, monitor your usage: The louder the sound, the shorter the time you should be exposed to it. Conversely, the softer the sound, the longer you can listen safely. For detailed information on preventing noise-induced hearing loss (NIHL) and a comprehensive list of harmful noise levels, visit the Hearing Health Foundation at www.df.org.
- Turn down the volume on the speaker before turning on audio playback.
- Do not use this product for anything other than what it was intended for.
- Do not open, modify, or disassemble this product. There are no serviceable parts inside.
- This product contains a non-replaceable rechargeable lithium-ion battery. When discarding, follow your local/state guidelines.
- Performance can be affected by the environment or when the product becomes discharged.
- Charge the product fully before storing it for a long period. NOTE: Lithium-ion batteries will self-discharge over time. To ensure battery life, do not store the product in a discharged state for a long period. Leaving the battery discharged for too long can render it unchargeable.
- Disconnect the USB cable once the product is fully charged.
- Interruption can be caused by obstacles between the product and Bluetooth device, by Wi-Fi or other high-frequency signals, or if the product is brought out of range of the Bluetooth device.
- Do not expose the product to extremely high or extremely low temperatures.
- Do not expose the product to heat sources or leave in a location that is likely to get excessively hot (such as the inside of a hot vehicle).
- Do not let the product get wet.
- Do not use abrasive cleaning solvents to clean the product. Use a soft, dry cloth only.
- This product is not a toy. Do not allow children or others who require supervision to use the product unsupervised.

INTRODUCTION

Thank you for choosing the Monster Mag Flux Bluetooth™ Speaker! This miniature magnetic speaker syncs wirelessly to your smartphone for ultra-rich music, calls, and audio. Easily snap the speaker to the back of your magnetic smartphone and choose from 5 RGBIC multicolor light effects that flow and glow through a sleek, translucent exterior. The speaker recharges quickly with the included USB cable, and you can sync two speakers together to experience immersive sounds and color-sync with True Wireless Stereo (second speaker sold separately).

FEATURES

- Syncs wirelessly to your Bluetooth device within 33 ft., or use a MicroSD card (32GB max, sold separately)
- Enjoy crisp music, calls, and audio with 40mm driver
- Choose from 5 multicolor accent light effects: rainbow flow, smooth color-changing, breathing red, breathing blue, and breathing green
- Snaps to compatible magnetic smartphones,* or use the included adapter ring
- Connect a second speaker for True Wireless Audio and color-sync effects (second speaker sold separately)
- Wearable and storage-friendly with the included lanyard
- Recharges in 1.5 hours for up to 2 hours of runtime

*Works with iPhone® series 12 and newer

WHAT'S INCLUDED

- Mag Flux BT Speaker
- 1.6ft USB-C to USB-A cable
- Magnetic Adapter Ring
- 7-inch Lanyard
- User Manual

SPECIFICATIONS

- Input: 5V/1A
- Output: 5W
- Driver Size: 40mm
- Impedance: 2.7Ω
- Sensitivity: 80db
- Number of LEDs: 3
- Battery Capacity: 500mAh
- Charging Time: 1.5H
- Playback Time: 2H
- Bluetooth Version: 5.3
- USB Cable Length: 1.64ft / 50cm
- MicroSD Size: 32GB Max

AT A GLANCE

- RGBIC Passive Bass Radiator
- Speaker
- Microphone
- Volume Down / Previous Song
- Multifunction On/Off
- Volume Up / Next Song
- MicroSD Port
- USB-C Port & LED Indicator
- Lanyard Hole
- Magnetic Surface
- 7-inch Lanyard
- 1.6 ft. USB-C to USB-A Cable
- Magnetic Adapter Ring

NOT SHOWN



SET UP

Remove all components from the package and charge your speaker fully before first use.

HOW TO CHARGE

- Insert the USB-C end of the included charging cable into the USB-C port on the speaker. Insert the other end into a USB port or appropriate power adapter (sold separately).
- The LED indicator light (behind the USB-C port) will illuminate red as the speaker charges and will turn off when the speaker is fully charged.

NOTE: When the speaker battery drops below 5%, you will hear an audio prompt that says: "Low Battery."

ATTACH THE LANYARD

Your speaker comes with an attachable lanyard for travel and storage. To attach the lanyard:

- Insert the narrow end of the lanyard through one hole in the speaker's lanyard slot and pull it out through the other side.
- Thread the thicker end of the lanyard through the narrow loop you just pulled through.
- Pull to tighten and secure the lanyard in place.

MOUNT YOUR SPEAKER

Your speaker features a built-in magnetic surface that snaps to the back of compatible magnetic iPhone® smartphones (series 12 and newer). For other smartphones, you can attach the included magnetic adapter ring to your smartphone case to create a suitable magnetic surface:

- Clean the back of your smartphone case to ensure it is free of dust and debris.

- Peel off the protective film from the adhesive side of the included magnetic adapter ring.
- Firmly press the magnetic adapter ring onto your desired location in one attempt.

Note that the ring is designed for single use only. Once removed, the adhesive loses its stickiness and cannot be reapplied.

⚠ CAUTION: DO NOT USE WHILE WIRELESS CHARGING

The magnetic adapter ring is designed for use with smartphone cases. If you place it on the back of your smartphone, you must remove it before placing your smartphone on a wireless charger. Wireless charging could heat the metal ring, causing damage to the device or burn risks.

The magnetic adapter ring should not be used with battery charging cases. It is only intended for use with standard phone cases.

PAIR TO YOUR SMARTPHONE WITH BLUETOOTH

Follow these steps to pair the speaker to your smartphone:

- Press and hold the Multi-Function On/Off button until the speaker powers on. You will hear an audio prompt that says: "Power On." After that, you will hear a Bluetooth prompt that says: "Bluetooth ready for connection." This indicates that your speaker is in pairing mode.
- Go to the Bluetooth section of your smartphone settings and select Monster Mag Flux from the list of available devices to begin the pairing process.
- You will hear an audio prompt that says "Bluetooth Connected" to indicate that pairing is complete.
- To remove your speaker from Bluetooth, disconnect it through your smartphone's Bluetooth settings. You will hear an audio prompt to indicate that the Bluetooth is disconnected.

If you are unable to connect your speaker to your smartphone with Bluetooth, try the following:

- Ensure the speaker and your smartphone are turned on and fully charged.
- Make sure your smartphone's Bluetooth setting is switched on.
- Restart your smartphone.

NOTE: Instead of connecting to your smartphone and playing audio through Bluetooth, you can insert a MicroSD card into the port on the side of your speaker and play audio directly from the card (32GB max, sold separately).

CONNECT TWO SPEAKERS FOR TWS + COLOR-SYNC

True Wireless Stereo (TWS) mimics immersive stereo sound by wirelessly pairing two speakers to create left and right audio channels. In TWS mode, both speakers will synchronize certain LED lighting effects with Color Sync, adding a visual dimension to the rich sound experience.

To enter TWS mode, you will need a second speaker (sold separately).

Power on both speakers, and make sure they are within ~32 feet of each other.

Triple-press the Multifunction On/Off button (press 3 times) on either speaker to automatically put them into TWS mode. You will hear an audio prompt when this step is complete.

Go to the Bluetooth section of your smartphone settings and select Monster Mag Flux from the list of available devices to pair the 2x speakers to your smartphone.

Once connected, your speakers will play simultaneous TWS audio. When you change the LED lighting effect on one speaker, the other one will change to match it, with some effects displaying Color Sync visual synchronization.

NOTE: If you want to exit TWS mode, triple-press the Multifunction On/Off button (press 3 times) on either speaker. After that, your smartphone will remain connected via Bluetooth to one speaker.

KEY FUNCTIONS:

POWER ON/OFF: Press and hold the Multifunction On/Off button

CHANGE THE ACCENT LIGHT: Double-press (press 2 times quickly) the Multifunction On/Off button to cycle through 5 RGBIC multicolor light effects: Rainbow Flow > Smooth Color-Changing > Breathing Red > Breathing Blue > Breathing Green

AUDIO & MUSIC CONTROLS:

PLAY/PAUSE AUDIO: Press the Multifunction On/Off button

PREVIOUS SONG: Double-press (press 2 times quickly) the Previous Song button (-)

NEXT SONG: Double-press (press 2 times quickly) the Next Song button (+)

DECREASE VOLUME: Press the Volume Down button (-)

INCREASE VOLUME: Press the Volume Up button (+)

CALL CONTROLS:

Your speaker must be connected to your device via Bluetooth to make and accept calls.

ANSWER INCOMING CALL / HANG UP A CALL: Press the Multifunction On/Off button.

NOTE: You will hear an audio prompt notifying you when there is an incoming call.

REJECT AN INCOMING CALL: Press and hold the Multifunction On/Off button for 2 seconds.

TIPS

- Performance can be affected by the environment or when your speaker becomes discharged.
- Interruption can be caused by obstacles between the speaker and your smartphone or Bluetooth device, by Wi-Fi or other high-frequency signals, or if the speaker is brought out of range of the smartphone or Bluetooth device (approximately 33 feet).
- To maintain healthy battery performance, charge the speaker periodically if not in use.
- To clean, wipe the speaker's exterior only with a soft, clean cloth. Do not use abrasive cleaning solvents.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

MONSTER

The illustrated products and specifications may differ slightly from those supplied. The M Monster logo and the M Slice logo are trademarks or registered trademarks of Monster, Inc. or its subsidiaries in the U.S. and other countries and are used under license. The Bluetooth® mark and logos are registered trademarks owned by Bluetooth Sig. Inc. and any use of such marks by MCT/JEM is under license. All other brand names are trademarks of their respective owners. Neither Jem Accessories, Inc. nor Monster, Inc. is affiliated with the respective owners of their trademarks. Licensed and Manufactured by Jem Accessories, Inc. Edison, NJ 08817.

WARRANTY

Jem Accessories, Inc. Limited Warranty Policy for Monster Products Last Updated: March 27, 2020

This limited warranty contains important information about your rights and obligations, as well as limitations and exclusions that may apply to you.

1. **WHAT THIS LIMITED WARRANTY COVERS; PERIOD OF COVERAGE** Jem Accessories, Inc. ("Jem Accessories"), 32 Brunswick Ave, Edison, New Jersey, USA, warrants to the owner of the endorsed Monster branded product contained in this box ("Product") will be free from defects in materials and workmanship for a period of one year. Notwithstanding the foregoing, the Warranty Period for a factory refurbished Product is one (1) year, even if installed by a professional. If the Product fails to conform to this Limited Warranty during the Warranty Period, Jem Accessories will, at its sole discretion, either (a) repair or replace any defective Product or component, with proof of purchase using original documentation. Repair or replacement may be made with a new or refurbished product or components, at Jem Accessories's sole discretion. If the Product or a component incorporated within it is no longer available, Jem Accessories may, at Jem Accessories's sole discretion, replace the Product with a similar product of similar function. This is your sole and exclusive remedy for breach of this Limited Warranty. Any Product that has either been repaired or replaced under this Limited Warranty will be covered by the terms of this Limited Warranty for the longer of (a) ninety (90) days from the date of delivery of the repaired Product or replacement Product, or (b) the remaining Warranty Period. This Limited Warranty is not transferable from the original purchaser to subsequent owners.

2. **TOTAL SATISFACTION RETURN POLICY** If you are the original purchaser of the Product and you are not satisfied with this Product for any reason, you may return it in its original condition to the retailer in compliance with the retailer's return policy.

3. **WARRANTY CONDITIONS; HOW TO GET SERVICE IF YOU WANT TO CLAIM UNDER THIS LIMITED WARRANTY** Before making a claim under this Limited Warranty, the owner of the Product must (a) visit monsterilluminescence.com/support during the Warranty Period to provide notice of your warranty claim and describe the alleged failure, and (b) comply with Jem Accessories (or its authorized distributor's) return shipping instructions. Jem Accessories will have no warranty obligations with respect to a returned Product if it determines, at its reasonable discretion after examination of the returned Product, that the Product is an Ineligible Product (defined below).

4. **WHAT THIS LIMITED WARRANTY DOES NOT COVER** This Limited Warranty does not cover the following (collectively "Ineligible Products"): (i) Products marked as "sample" or "Not for Sale," or sold "AS IS"; (ii) Products that have been subject to: (a) modifications, alterations, tampering, or improper maintenance or repairs; (b) handling, storage, installation, testing, or use not in accordance with any quick start guide, manual or other instructions provided by Jem Accessories; (c) abuse or misuse of the Product; (d) breakdowns, fluctuations, or interruptions in electric power or the telecommunications network; or (e) Acts of God, including but not limited to lightning, flood, tornado, earthquake, or hurricane; or (iii) any non-Jem Accessories branded hardware products, even if packaged or sold with Jem Accessories hardware. This Limited Warranty does not cover consumable parts, including batteries, unless damage is due to defects in materials or workmanship of the Product, or software (even if packaged or sold with the product). Jem Accessories recommends that you use only authorized service providers for maintenance or repair. Unauthorized use of the Product or software can impair the Product's performance and may invalidate this Limited Warranty.

5. **DISCLAIMER OF WARRANTIES** Except as stated above in this limited warranty, and to the maximum extent permitted by applicable law, Jem Accessories disclaims all express, implied, and statutory warranties and conditions with respect to the product, including the implied warranties of merchantability and fitness for a particular purpose. To the maximum extent permitted by applicable law, Jem Accessories also limits the duration of any applicable implied warranties or conditions to the duration of this limited warranty.

6. **LIMITATION OF DAMAGES** In addition to the above warranty disclaimers, in no event will Jem Accessories be liable for any consequential, incidental, exemplary, or special damages, including any damages for lost data or lost profits, arising from or relating to this limited warranty or the product, and Jem Accessories's total cumulative liability arising from or related to this limited warranty or the product will not exceed the amount actually paid for the product by the original purchaser.

7. **LIMITATION OF LIABILITY** The Jem Accessories online services at monsterilluminescence.com ("services") provide you information ("product information") regarding your Jem Accessories products or other peripherals connected to your products ("product peripherals"). The type of product peripherals that may be connected to your product may change from time to time. Without limiting the generality of the disclaimers above, all product information is provided for your convenience, "as is", and "as available". Jem Accessories does not represent, warrant, or guarantee that product information will be available, accurate, or reliable or that product information or use of the services or product will provide safety in your home. You use all product information, the services, and the product at your own discretion and risk. You will be solely responsible for (and Jem Accessories disclaims) any and all loss, liability, or damages, including to your wiring, fixtures, electricity, home, product, product peripherals, computer, mobile device, and all other items and pets in your home, resulting from your use of the product information, services, or product. Product information provided by the services is not intended as a substitute for direct means of obtaining the information. For example, a notification provided through the service is not intended as a substitute for audible and visible indications in the home and on the product, nor for a third party monitoring service that monitors alarm state.

8. **YOUR RIGHTS AND THIS LIMITED WARRANTY** This Limited Warranty gives you specific legal rights. You may also have other legal rights that vary by state, province, or jurisdiction. Likewise, some of the limitations in this Limited Warranty may not apply in certain states, provinces or jurisdictions. The terms of this Limited Warranty will apply to the extent permitted by applicable law. For a full description of your legal rights you should refer to the laws applicable in your jurisdiction and you may wish to contact a relevant consumer advisory service. If you need to start a warranty claim for your Monster Smart device, please reach out to Customer Support by emailing customerservice@monsterilluminescence.com or calling our support number 866-246-2008. Please allow 7-10 business days to process warranty claims. Customers located outside of U.S. will be responsible for all shipping costs.

2ND YEAR EXTENDED WARRANTY

Register your Monster product to extend your warranty as listed above for one additional year. Scan the QR code on the cover of this manual to register your product, or visit <https://monsterilluminescence.com/limited-warranty/>