Model No.: MH22203




# TH300

# **QUICK START GUIDE**

Please read this Quick Start Guide carefully and keep it for future use.


## **Product Overview**




Open earphones x2 (L & R)



Charging case x1



USB-C cable x1




Quick start guide and warranty card



Eartips x 3 Pairs (The M size is installed on the earphones)

### Charging

Before using the "**Monster TH300**", please connect the USB-C cable to a power adapter to begin charging. Fully charge the earphones and the charging case before the first use.



#### Power On/Off

When open the charging case, the earphones will power on automatically. If you want to turn off the earphones, please put the earphones into the charging case and close the cover, the earphones will power off and charge at the same time.

#### **Pairing**


When open the charging case, the earphones will power on automatically.

For new device connection, turn on the Bluetooth in your device and choose "Monster TH300" from the Bluetooth list to connect. You will hear system prompts after the earphones are connected to the device.


If the earphones have been connected before, they will connect to the last connected device automatically after being turned on.

### Wearing

Put the "Monster TH300" onto your ears and rotate to fit comfortably to get the best wearing and sound quality experience.




### MFB Operation



#### Reset

In the power on state, touch the MFB of earphones 5 times (two earphones at the same time), and the earphones will automatically shut down and restore the factory settings.

### **Smart Charging Case Operation**



- After the screen is turned off without operation, double-click the screen to light up;
- Short press the MFB button of the charging compartment for 1 time to turn on the screensaver or turn off the screen.
- Open and close the charging cover, you can turn on the screen or turn off the screen

Swipe left and right to enter the main interface of the function

## Smart Charging Case function display






















# **Additional Operation**

Answercall	Press L or R twice
End call	Press L or R twice
Reject call	Press MFB 3seconds
LED indicator (earphone)	
Pairing is successful	The white light on 1s and then turn off
Pairing timed out	The red light on 2s and then turn off
Charging	Red flashes
Fully charged	Red off
Low battery	Red flashes
LED screen (charging case)	
Power on/off	In the power-off state, press and hold
	the MFB to power on
	In the power-on state, press and hold
	the MFB to pop up the shutdown or
	restart interface, slide left and right to
	slide back to the main interface
Charging	A white lightning bolt symbol is
	displayed when the screen is locked
	When the screen is unlocked, the menu
	bar displays the percentage of battery
	in real time
Low battery	When the screen is unlocked, the menu
	bar displays the charging case in real
	time, Percentage battery and the icon
	turns red and flashes slowly

Music playback	Play/Pause: Tap the play icon
	Next song: Tap the right icon
	Previous song: Tap the left icon
Volume adjustment	Volume up: Tap the right icon
	Volume down: Tap the left icon
Ambient sound	Tap the icon to select a ambient
	sound mode, From left to right:
	Normal/Noise Reduction/
	Transparent
Equalizer	Tap the left/right icon
	to select EQ sounds
Light level	Tap the left/right icon
	to select screen brightness
Language switch	Tap the left/right icon
	to select a language
Find my earphone	Tap the left/right ear icon
	and select Start accordingly (If you
	cancel, you will return), and the L/R
	earphone will sound accordingly.
	Tap the stop button
	to disappear and go back
Time setting	When connected to a mobile phone,
	the network time is automatically
	calibrated

Bluetooth to take pictures	When your phone turns on the
	camera, tap the on-screen
	camera icon to start the remote
	photo taking feature on your
	phone
Answer an incoming call	When the earphones remains
	connected outside the charging
	case, tap the storage screen
	Answer icon
Hang up	When the earphones remains
	connected outside the charging
	case, tap the storage screen
	Hang up icon
Reject an incoming call	When the earphones remains
	connected outside the charging
	case, tap the storage screen
	Hang up icon

#### **Attention**

- \*Private replacement of batteries without permission is not recommended.
- \*Batteries [battery packs or battery combinations] should not be exposed to lighting, baking or similar overheating environments.
- \*The input voltage and current standard ≤ 5V/1A when charging the headset charging compartment from an external power source;

#### FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.
  Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
  This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received. Including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. FCC ID: 2AVD2-MH22203